

Field Termination Plug Installing Instruction

FPS

①

Copper Sticker
10mm
30mm

②

Boot
Cable

③

30mm Min.
10mm
or
30mm Min.
10mm

S/FTP U/FTP.F/UTP

④

30mm Min.
10mm
Copper Sticker

⑤

30mm Min.
10mm
Wrapped up

⑥

⑦

5-8mm Max.

⑧

⑨

Cut front row wires flush

⑩

Cut rear row wires flush

⑪

0.2mm Max.

⑫

KEY

⑬

1

⑭

2
3

⑮

⑯

Legend

| | | | | | | | |
|-----|---|-----|----|------|---|------|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| W-G | G | W-O | BL | W-BL | O | W-BR | BR |

Pin assignment T568A

| | | | | | | | |
|-----|---|-----|----|------|---|------|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| W-O | O | W-G | BL | W-BL | G | W-BR | BR |

Pin assignment T568B

| | Solid | Stranded | Cable (O.D.) |
|-----|----------|----------|--------------|
| C6A | 23~26AWG | 23~26AWG | 5.6~8.5mm |
| C8 | 22~24AWG | 22~24AWG | 5.6~8.5mm |